



## **Installation Instructions for ZSpeed Aluminum Splash Shield**

**Included in the kit are 3 "Rivet nuts" and the tool to install them.**

**These 3 Rivnuts will be installed into the aluminum core support where the factory uses plastic push style clips. This makes the shield much stronger with stronger attachment points, Do not skip this step!**

**To install the Rivnuts enlarge the 3 holes in the lower core support with a 11/32" inch drill bit only. Using a hammer, tap riv nut into hole.**

**It should be a tight fit, you can enlarge hole slightly if needed.**



**Using included tool w/nut, thread tool into rivnut until it bottoms out.**

**Hold nut with ½" wrench (lock washer facing rivnut) and tighten the smaller 10mm bolt keeping tool and Rivnut flat with surface, The Rivnut will crimp into the hole as you tighten the smaller bolt. Tighten until you feel the small bolt get tighter and snug it up until Rivnut is completely crimped into hole. DO NOT OVERTIGHTEN Remove tool &**

**Install shield using supplied hardware.**